


Royal Blue

BD Vacutainer Tube Conversion Guide

BD Vacutainer	Tube Conversion Guide			
NEW BD Vacutainer® Tube Cap/Color	Additive and Tube Size/Volume	Number of Inversions	Primary Testing Disciplines	Previous Greiner Vacuette® Tube Type/Color
Blue	Sodium Citrate 13 x 75 / 2.7 mL	3-4	Coagulation	Blue
Gold	Clot activator and gel for serum separation 13 x 75 / 3.5 mL 13 x 100 / 5 mL	5	Chemistry Immunochemistry Some TDMs	Red Gel
Red	Silicone coated 13 x 75 / 3mL 13 x 100 / 6 mL	5	Some TDMs Chemistry Viral Markers	Red
Light Green	Lithium Heparin and gel for plasma separation 13 x 75 / 3 mL 13 x 100 / 4.5 mL	8	Plasma Chemistry Immunochemistry	Green
Green	Lithium Heparin (no gel) 13 x 75 / 2 mL 13 x 100 / 6 mL	8	Plasma Chemistry	Green
Green	Sodium Heparin (no gel) 13 x 75 / 2 mL 13 x 75 / 4 mL 13 x 100 / 6 mL	8	Flow Cytometry Cytogenetics	Green
Lavender	Spray coated K ₂ EDTA 13 x 75 / 3 mL 13 x 100 / 6 mL	8	Hematology Cytogenetics	Lavender
Pink	Spray coated K2EDTA 13 x 100 / 6 mL	8	Transfusion Services	Pink
Gray	Sodium Fluoride / K ⁺ Oxalate 13 x 75 / 2 mL	8	Some chemistries (e.g. lactic acid, tolerance glucose as appropriate)	Gray
No Change	Clot activator 13 x 100 / 6 mL	8	Trace elements Toxicology	Royal Blue

BD Vacutainer® Order of Draw



NOTE: Gold Gel tubes should clot for 30 minutes before centrifugation. Red, no additive tubes should clot for 60 minutes before centrifugation. Tubes should be centrifuged within 2 hours of collection. Gel tubes should not be spun in a refrigerated centrifuge.

BD Vacutainer Centrifugation

Tube Type	Recommended g-force relative centrifugal force (rcf)	Recommended Time (Minutes)
Vacutainer® Non-Gel Tubes	1000 – 1300 g	10*
Vacutainer® Serum Clot Activator w/ Gel Tubes	1000 – 1300 g	10*
Vacutainer® Plasma Tubes with Gel	1000 – 1300 g	10*
Vacutainer® Coagulation Tubes (Sodium Citrate)		
Platelet tests (Platelet rich plasma)	150 g	5
Routine tests (Platelet poor plasma)	1500 g	15
Preparation for deep freeze plasma	2500 - 3000 q	20

^{*}Time stated is for swing bucket centrifuges. If samples are spun in fixed angle centrifuges the centrifugation time should be increased to 15 minutes. If the minimum g force cannot be met (swing bucket or fixed rotor centrifuge) increase the spin time to 20 minutes.